

Charlotte K. Lowrie

Canon® EOS 50D

Digital Field Guide



Full Color Throughout!

Canon® EOS 50D

Digital Field Guide

Canon® EOS 50D Digital Field Guide

Charlotte K. Lowrie



WILEY

Wiley Publishing, Inc.

Canon® EOS 50D Digital Field Guide

Published by
Wiley Publishing, Inc.
10475 Crosspoint Boulevard
Indianapolis, IN 46256
www.wiley.com

Copyright © 2009 by Wiley Publishing, Inc., Indianapolis, Indiana

Published simultaneously in Canada

ISBN: 978-0-470-45559-3

Manufactured in the United States of America

10 9 8 7 6 5 4 3 2 1

No part of this publication may be reproduced, stored in a retrieval system or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, scanning or otherwise, except as permitted under Sections 107 or 108 of the 1976 United States Copyright Act, without either the prior written permission of the Publisher, or authorization through payment of the appropriate per-copy fee to the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, (978) 750-8400, fax (978) 646-8600. Requests to the Publisher for permission should be addressed to the Permissions Department, John Wiley & Sons, Inc., 111 River Street, Hoboken, NJ 07030, (201) 748-6011, fax (201) 748-6008, or online at <http://www.wiley.com/go/permissions>.

LIMIT OF LIABILITY/DISCLAIMER OF WARRANTY: THE PUBLISHER AND THE AUTHOR MAKE NO REPRESENTATIONS OR WARRANTIES WITH RESPECT TO THE ACCURACY OR COMPLETENESS OF THE CONTENTS OF THIS WORK AND SPECIFICALLY DISCLAIM ALL WARRANTIES, INCLUDING WITHOUT LIMITATION WARRANTIES OF FITNESS FOR A PARTICULAR PURPOSE. NO WARRANTY MAY BE CREATED OR EXTENDED BY SALES OR PROMOTIONAL MATERIALS. THE ADVICE AND STRATEGIES CONTAINED HEREIN MAY NOT BE SUITABLE FOR EVERY SITUATION. THIS WORK IS SOLD WITH THE UNDERSTANDING THAT THE PUBLISHER IS NOT ENGAGED IN RENDERING LEGAL, ACCOUNTING, OR OTHER PROFESSIONAL SERVICES. IF PROFESSIONAL ASSISTANCE IS REQUIRED, THE SERVICES OF A COMPETENT PROFESSIONAL PERSON SHOULD BE SOUGHT. NEITHER THE PUBLISHER NOR THE AUTHOR SHALL BE LIABLE FOR DAMAGES ARISING HEREFROM. THE FACT THAT AN ORGANIZATION OR WEB SITE IS REFERRED TO IN THIS WORK AS A CITATION AND/OR A POTENTIAL SOURCE OF FURTHER INFORMATION DOES NOT MEAN THAT THE AUTHOR OR THE PUBLISHER ENDORSES THE INFORMATION THE ORGANIZATION OF WEB SITE MAY PROVIDE OR RECOMMENDATIONS IT MAY MAKE. FURTHER, READERS SHOULD BE AWARE THAT INTERNET WEB SITES LISTED IN THIS WORK MAY HAVE CHANGED OR DISAPPEARED BETWEEN WHEN THIS WORK WAS WRITTEN AND WHEN IT IS READ.

For general information on our other products and services or to obtain technical support, please contact our Customer Care Department within the U.S. at (800) 762-2974, outside the U.S. at (317) 572-3993 or fax (317) 572-4002.

Wiley also publishes its books in a variety of electronic formats. Some content that appears in print may not be available in electronic books.

Library of Congress Control Number: 2009920910

Trademarks: Wiley and the Wiley Publishing logo are trademarks or registered trademarks of John Wiley & Sons, Inc. and/or its affiliates. Trademark information here. All other trademarks are the property of their respective owners. Wiley Publishing, Inc. is not associated with any product or vendor mentioned in this book.



About the Author

Charlotte K. Lowrie is a professional editorial, portrait, and stock photographer and an award-winning writer based in the Seattle, Washington area. Her writing and photography have appeared in newsstand magazines and on Web sites. Her images have appeared on the Canon Digital Learning Center, and she is a featured photographer on www.takegreatpictures.com. She is the author of 11 books including the best-selling *Canon EOS Rebel XSi/450D Digital Field Guide* and the *Canon EOS Rebel XTi/400D Digital Field Guide*. She is the co-author of *Exposure and Lighting for Digital Photographers Only*. In addition to shooting ongoing photography assignments, Charlotte teaches two photography classes at BetterPhoto.com every month.

You can see more of Charlotte's images on her Web site at wordsandphotos.org.

Credits

Associate Acquisitions Editor

Aaron Black

Senior Project Editor

Cricket Krengel

Technical Editor

Ben Holland

Copy Editor

Kim Heusel

Editorial Manager

Robyn Siesky

Business Manager

Amy Knies

Senior Marketing Manager

Sandy Smith

**Vice President and Executive Group
Publisher**

Richard Swadley

Vice President and Executive Publisher

Barry Pruett

Senior Project Coordinator

Kristie Rees

Graphics and Production Specialists

Ana Carrillo

Andrea Hornberger

Jennifer Mayberry

Christin Swinford

Quality Control Technicians

Melissa Cossell

Amanda Graham

Proofreading and Indexing

Penny Stuart

Broccoli Information Management

***This book I dedicated in loving memory to
Vera Sauer, a woman whose love, strength,
integrity, and faith were, and continue to
be, an inspiration to all who knew her.***

Contents at a Glance

Introduction	xvii
--------------------	------

Part I: Navigating and Setting Up the EOS 50D 1

Chapter 1: Roadmap to the EOS 50D	3
Chapter 2: Setting Up the EOS 50D	25
Chapter 3: Controlling Exposure and Focus	47
Chapter 4: Getting Great Color	91
Chapter 5: Customizing the EOS 50D	115

Part II: Doing More with the EOS 50D 133

Chapter 6: Shooting in Live View or Tethered	135
Chapter 7: Working with Flash and Studio Lights	147
Chapter 8: Lenses and Accessories	165
Chapter 9: Using the EOS 50D in the Field	189

Part III: Appendixes.....221

Appendix A: The Fundamentals of Exposure	223
Appendix B: Exploring RAW Capture	235
Appendix C: Maintaining the 50D	243
Glossary	249

Index	257
-------------	-----

Contents

Introduction	xvii	Lens Controls	17
		Viewfinder display	18
		Camera menus	19
Part I: Navigating and Setting Up the EOS 50D	1	Chapter 2: Setting Up the EOS 50D	25
Chapter 1: Roadmap to the EOS 50D	3		
			
Key Technology	3	Choosing Image Format and Quality	25
Camera Features Overview	4	JPEG	26
Front of the camera	6	RAW and sRAW	27
Top of the camera	7	Getting the best of both JPEG and RAW	30
Back of the camera	11	Working with Folders and File Numbering	32
Side of the camera	15	Creating and selecting folders	32
Bottom of the camera	16	Setting file numbering	33
		Continuous file numbering	34
		Auto reset	35
		Manual reset	35
		Miscellaneous Setup Options	37
		General setup options	37
		Add copyright information	40
		Image Playback Options	42
		Display and move through multiple images	43
		Displaying images on a TV	44
		Protecting images	45
		Erasing images	45

Chapter 3: Controlling Exposure and Focus 47



Working with Exposure	47
Defining exposure goals	48
Practical exposure considerations	48
Choosing a Shooting Mode	50
Creative Zone shooting modes	50
Program AE (P) shooting mode	51
Shutter-Priority AE (Tv) mode	52
Aperture-Priority AE (Av) mode	55
Manual (M) mode	56
Bulb exposures	57
A-DEP mode	58
C1 and C2 (Camera User Settings) modes	59
Basic Zone shooting modes	59
Creative Auto mode	60
Full Auto mode	62
Portrait mode	62
Landscape mode	63
Close-up mode	63
Sports mode	63
Night Portrait mode	64
Flash Off mode	64
Setting the ISO Sensitivity	64

Metering Light and Modifying Exposure	67
Using metering modes	68
Evaluating exposures	71
Brightness histogram	71
RGB histogram	71
Modifying and bracketing exposures	73
Auto Lighting Optimizer	74
Highlight Tone Priority	74
Safety Shift	75
Auto Exposure Lock	76
Exposure Compensation	77
Auto Exposure Bracketing	79
Using Autofocus	81
Choosing an autofocus mode	81
Choosing an autofocus point	83
Selecting a Drive Mode	87

Chapter 4: Getting Great Color 91



Working with Color	91
Choosing a color space	92
Setting the white balance	94
Setting a custom white balance	97
Setting a specific color temperature	100
Fine-tuning white balance	101
Using White Balance Auto Bracketing	101
Using White Balance Correction	102
Working with Picture Styles	103
Choosing and customizing Picture Styles	104
Registering a new Picture Style	108
Using the Picture Style Editor	109

Chapter 5: Customizing the EOS 50D 115



Exploring Custom Functions	116
Custom Function groupings	116
Custom Functions specifics	117
C.Fn I: Exposure	118
C.Fn II: Image	120

C.Fn III: Autofocus/Drive	122
C.Fn IV: Operation/Others	125
Setting Custom Functions	128
Registering Camera User Settings	129
Customizing My Menu	131


Part II: Doing More with the EOS 50D 133

Chapter 6: Shooting in Live View or Tethered 135



About Live View Shooting	135
Live View Features and Functions	136
Live View focus	137
Exposure simulation and metering	138
Silent shooting modes	138
Using a flash	139
Setting up for Live View Shooting	139
Working with Live View	141
Shooting in Live View	141
Shooting tethered or with a wireless connection	143

**Chapter 7: Working with Flash
and Studio Lights 147**



Flash Technology Basics	147
Shooting with the Built-in Flash	150
Working with the built-in flash	150
Red-eye Reduction	152
Modifying Flash Exposure	152
Flash Exposure Compensation	152
Flash Exposure Lock	154
Using Flash Control Options	155
Disabling the flash but enabling the flash's autofocus assist beam	157
Built-in flash techniques	158
Shooting with Speedlites and Studio Lighting	159
Using multiple Speedlites and studio lights	159
Exploring flash techniques	162
Bounce flash	162
Adding catchlights to the eyes	162

Using a Speedlite as an auxiliary light	163
Balancing lighting extremes	163

**Chapter 8: Lenses and
Accessories 165**



Evaluating Lens Choices for the 50D	165
Building a lens system	166
Understanding the focal-length multiplier	167
Types of Lenses	168
About zoom lenses	169
About prime lenses	170
Working with Different Types of Lenses	171
Using wide-angle lenses	171
Using telephoto lenses	173
Using normal lenses	174
Using macro lenses	175
Using tilt-and-shift lenses	177
Using Image Stabilized lenses	177

Calibrating and Fine-Tuning Lenses	179
Calibrating lenses for focus accuracy	179
Setting lens peripheral correction	181
Doing More with Lens Accessories	182
Lens extenders	182
Extension tubes and close-up lenses	183
Learning Lens Lingo and Technology	184

Chapter 9: Using the EOS 50D in the Field 189



Nature and Landscape Photography	190
Packing the camera bag	190
Setting up the 50D for outdoor shooting	193
Exposing average scenes	195
Basic exposure technique	197
Advanced exposure approach	199
Exposing nonaverage scenes	201
Shooting landscape and nature images	204

Portrait Photography	206
Selecting gear	207
Setting up the 50D for portrait shooting	208
Making natural-light portraits	209
Outdoor portraits	210
Window light portraits	211
Exposure approaches	211
Making studio portraits	212
Keep it simple	213
Event and Action Photography	214
Packing the gear bag	214
Setting up the 50D for event and action shooting	215
Shooting events and action	216
Exposure approaches	217
Shooting action images	218

Part III: Appendixes 221

Appendix A: The Fundamentals of Exposure 223



The Four Elements of Exposure	223
Light	224
Sensitivity: The role of ISO	225
Intensity: The role of the aperture	227
Wide aperture	227
Narrow aperture	227
Choosing an aperture	228
What is depth of field?	229
Time: The role of shutter speed	231
Equivalent Exposures	232
Putting It All Together	233

Appendix B: Exploring RAW Capture 235



Learning about RAW Capture	235
Canon's RAW Conversion Program	238
Sample RAW Image Conversion	240

Appendix C: Maintaining the 50D 243



Cleaning the Image Sensor	243
Mapping and removing dust	244
Cleaning the sensor manually	245
Updating Firmware and Software	246

Glossary 249



Index 257

Introduction

Welcome to the Canon EOS 50D Digital Field Guide. With the EOS 50D, Canon combined speed and responsiveness with high resolution and a full complement of features — all in a lightweight and fun-to-use camera. Whether this is your first digital SLR or you're an experienced photographer, this book is written to help you get the most from the camera. From personal experience, I know that the 50D is a fine tool that will help you realize and express your creative vision.

Achieving your creative vision with the 50D involves not only mastering the buttons, dials, and menus, but also learning what to expect from the camera as you work with it in the field, and, of course, your own skilled eye and creativity. It is in the field where you come to appreciate the camera's broad range of features, timesaving custom options, full creative control, and, of course, the data-rich images that the 50D delivers.

This book is designed to help you learn the basics and to go deeper into the camera so that you can take advantage of its full potential. If you're new to digital SLR's, then I suggest that you read at a high level, using the techniques that are described while saving the in-depth explanations for later. As you gain experience, then you can come back to the more detailed sections to understand more about the camera and photography itself. And if you're a more experienced photographer, I hope that the book will answer questions you may have, reveal new and creative ways to use the 50D, and inspire you to use the 50D to its full potential.

As a long-time photographer, I firmly believe that this book should not be only a reference book. Rather, I believe that photographers want to know how the camera responds and how it delivers in real shooting situations. I've used the EOS 50D long enough to be able to offer insights into the camera's performance and to share recommendations based on my experience. As readers often tell me, their preferences are different from my preferences. But you can use my recommendations as a springboard to setting up and shooting with the 50D in a way that suits your style and subject.

I hope that this book shows you things you didn't know before, that it clarifies concepts that were previously confusing, and, most important, I hope that it inspires you to make wonderful images. Writing this book was a rewarding journey for me. I hope that reading the book will be a rewarding journey into the creative world of photography for you.

Making the Most of This Book

As much as is practicable, this book follows a sequence from learning the camera controls to setting up the camera, shooting and focus controls, controlling all aspects of image color, setting Custom Functions, and using a flash. By the time that you finish reading Chapter 5, you will have a good understanding of what the camera offers from the top level through to the finer details. But more important, with Chapter 5, you have the opportunity to setup the camera for your most common scenes and subjects. The time saving of using the custom options on the 50D including the C shooting modes translates directly into time savings for you in the field.

The 50D offers Live View shooting with some enhancements over previous versions of Live View. Chapter 6 gives you a step-by-step guide on how to set up for and use Live View shooting, and what scenes and subjects are best suited for shooting with Live View. This chapter also discusses shooting with the 50D attached to the computer, or *tethered* shooting. You learn how you can control the camera entirely from your computer including setting an instant sort of Custom White Balance, changing exposure settings, and more.

Chapter 7 concentrates on using the built-in and an accessory flash unit, using multiple Speedlites with stands and light modifiers such as softboxes and umbrellas, and there is also a brief look at using the 50D with a studio lighting system.

I've seldom met a photographer who isn't looking to buy another lens. And in Chapter 8, you look at lenses and their characteristics. You can use these lens characteristics for both classic renderings as well as creative applications.

One of the distinguishing characteristics of the Digital Field Guide series of books is a concentration on shooting with cameras in real-world shooting scenarios. Chapter 9 is devoted to shooting in the field. Three common and broadly applicable areas are discussed: Landscape and Nature, Portraits, and Action and Events. From the information on these three subject areas, you can extrapolate to many other subjects including travel, architecture and interiors, documentary, and stock subject, environmental portraits, headshots, publicity, editorial assignments, and more. The focus of Chapter 9 is to provide suggestions and examples from my experience with the 50D that you can use or modify for your photography. Again, my experiences can serve as a starting place for you to setup your shooting.


Finally, Appendix A is a must read if you're new to photography. Here you learn the basics of photographic exposure. And if you're contemplating RAW shooting, be sure to read Appendix B that outlines the advantages, and takes a look at a sample RAW image conversion.

I hope that this book helps you not only make the most of your EOS 50D, but that it also inspires and challenges you in your daily shooting.

The editor, the staff at Wiley, and I hope that you enjoy reading this book as much as we enjoyed creating it for you.

Navigating and Setting Up the EOS 50D

P A R T



In This Part

Chapter 1
Roadmap to the EOS
50D

Chapter 2
Setting Up the EOS
50D

Chapter 3
Controlling Exposure
and Focus

Chapter 4
Getting Great Color

Chapter 5
Customizing the EOS
50D





Roadmap to the EOS 50D

CHAPTER



Three words can describe Canon's 50D dSLR — fast, sleek, and fun. It fits easily and comfortably in the hand with a compact yet substantial heft. It responds with the speed of a gazelle delivering images at a rate of 6.3 frames per second (fps) and at a stunning 15.1-megapixels. The EOS 50D is packed with Canon's latest features and technologies that collectively deliver speedy and reliable performance and superior image quality. Whether you're new to digital photography or a veteran, the EOS 50D hits a sweet spot of high image resolution, speed, and creative control.

This chapter puts some of the new features and technologies of the EOS 50D into everyday perspective and offers a roadmap to navigating the camera controls and menus. Where possible, I offer paradigms for using the camera that help you spend less time remembering what control to use and more time shooting.

Key Technology

Before we begin, it's worthwhile to look at key technology that the 50D offers. The first, the 15.1-megapixel image sensor at 4752×3168 pixels produces full-resolution prints at 15.5×10.7 inches at 300 ppi, or 19.4×13.4 inches at 240 ppi for inkjet prints. The new CMOS (complementary metal-oxide semiconductor) features Canon's newest technology including:

- ◆ **"Gapless" microlens technology and increased ISO range.** While the EOS 50D packs more and smaller pixels on a sensor that's the same size as the EOS 40D (4.7 versus 5.7 micron pixels sizes,



In This Chapter

Key technology

Camera features overview

Lens controls



respectively), the new sensor is engineered to increase each pixel's light sensitive area and to use a larger microlens over each pixel. The spaces between microlens on the sensor array are now gapless so that each microlens covers more of the pixel surface than in previous Canon digital SLR sensors. Thus the EOS 50D provides approximately 1 to 1.5 f-stops better digital noise performance at high ISO sensitivities than previous sensors. In everyday shooting, this translates into new opportunities for lowlight shooting particularly when you're using an Image-Stabilized (IS) lens.

- ♦ **DIGIC 4 processor.** Every new iteration of Canon's DIGIC processor improves the speed of image processing, and that's no less true with the fourth generation of Canon's on-board processor. The 14-bit DIGIC 4 processor offers 30 percent faster image processing than previous processors. It also offers increased functionality including full and variable resolutions; High ISO Noise Reduction options; Auto Lighting Optimizer with three selectable levels; and Peripheral Illumination Correction, or vignette control, for JPEG capture (and vignette control for RAW files using Canon's Digital Photo Professional program). And the faster processor results in a faster and more responsive autofocus system. Taken together, DIGIC 4 performs more processing with more selectable options for image correction — all with no appreciable loss of speed and performance.

Camera Features Overview

If you've had your EOS 50D for any amount of time, then you are likely familiar with most of the controls on the camera. However, the following sections are designed to provide a paradigm for using the controls in logical and efficient ways because once you learn the overall design, you can make camera adjustments more efficiently. And chances are that there are some buttons and controls that you haven't figured out yet, so these sections help you make full use of all the 50D has to offer.

Note

It's important to become familiar with the names of camera controls now because I refer to these names throughout this book.

There are three main controls that can be used together or separately to control most functions on the EOS 50D. Here is a quick synopsis of the controls and when to use them.

- ♦ **Main dial and Quick Control dial.** You use the Main and Quick Control dials to make changes for the for dual-function buttons located along the top LCD panel such as the AF-Drive button (Autofocus mode and Drive mode). Use the Main dial to change the first named function. So for the AF-Drive button, you turn the Main dial to change the Autofocus mode. For the second named function, you make changes using the Quick Control dial. So, you turn the Quick Control dial to change the Drive mode. This holds true for the

Metering mode-White Balance and ISO-Flash Compensation buttons on the camera as well. Some camera menu screens such as the Quality screen also use the Main and Quick Control dials for selecting different values on the screen.

- ♦ **Multi-controller.** This eight-way control functions as a button when it's pressed, and as a joystick when it's tilted in any direction. With the new Quick Control screen, the Multi-controller is the primary control. Ironically, the Quick Control dial would seem to be the logical choice to activate the Quick Control screen, but, such is not the case. To activate the Quick Control menu, press the center of the Multi-controller, and then tilt the Multi-controller to move around the screen. Once an option is selected on the Quick Control screen, you can turn the Quick Control dial or Main dial to make changes.



1.2 The Multi-controller

- ♦ **Set button.** The Set button is located in the center of the Quick Control dial, and you use it to confirm changes you make to many menu items and to open sub-menus. When you're using the Quick Control screen, you can select a setting, such as White Balance, and then press the Set button to display all the options for the setting, in this case, the White Balance screen showing all White Balance options.



Main dial



Quick Control dial

1.1 The Main and Quick Control dials

Front of the camera

While you, as the photographer, don't often see the front of the camera, it includes the nicely sculpted grip that increases control and balance when handling the camera, and it includes controls that you use often.

The front-of-the-camera features include, from left to right side, the following:

- ♦ **Shutter button.** The Shutter button is a two-step control. When you press the Shutter button halfway, the 50D meters the light in the scene and focuses on the subject using either the autofocus (AF) point that you've selected or at the AF point(s) that the camera's selected automatically. Completely pressing the Shutter button fires the shutter to make the picture. In

High-Speed or Low-Speed Continuous drive mode, pressing and holding the Shutter button starts burst shooting at either 3 frames per second (fps) or 6.3 fps, respectively. In Self-timer modes, pressing the Shutter button completely initiates the 2- or 10-second timer, and after the timer delay, the shutter fires to make the picture.

- ♦ **Red-eye Reduction/Self-timer lamp.** When using the built-in flash with the Red-eye reduction option turned on, this lamp lights to help reduce pupil size to reduce the appearance of red in the subject's eyes if the subject looks at the lamp. In the two Self-timer modes, this lamp flashes to count down the seconds, either 2 or 10 seconds, to shutter release.



1.3 EOS 50D camera front

- ♦ **Mirror.** As you compose an image, the reflex mirror reflects light from the lens to the pentaprism so that you can see in the eyepiece of the viewfinder what will be captured by the imaging sensor. The viewfinder offers 95 percent frame coverage. In Live View shooting the mirror is flipped up to allow a live view of the scene. If you are using Live mode focusing, the mirror flips down to focus, thereby suspending Live View momentarily.
- ♦ **Lens mount and contacts.** The lens mount is compatible with Canon's EF and EF-S lenses. EF-S lenses are compatible with only the cropped image sensor size of the 50D and other Canon EOS digital SLR cameras. EF lenses are compatible with all EOS digital SLRs. The lens mount includes a red index marker that's used to line up EF-mount lenses and a white index mount marker that's used to line up EF-S lenses.
- ♦ **Depth of field preview button.** Pressing this button stops down the lens diaphragm to the currently selected aperture so that you can preview the depth of field in the viewfinder. The larger the area of darkness, the more extensive the depth of field will be. The button can be used in regular and Live View shooting. If the lens is set to the maximum aperture, the Depth-of-field preview button can't be depressed because the diaphragm is already fully open.
- ♦ **Lens Release button.** This button releases the lens from the lens mount. To disengage the lens, depress and hold down the Lens Release button as you turn the lens so that the red or white index mark moves toward the top of the camera.

- ♦ **Flash button.** In P, Tv, Av, M, A-DEP, and C shooting modes, press this button to pop up and use the built-in flash. In automatic modes such as CA, Portrait, Landscape, and so on, pressing the Flash button has no effect because the camera automatically determines when to use the built-in flash.

Top of the camera

Dials and controls on the top of the camera provide access to frequently accessed shooting functions in addition to the hot shoe and diopter control. Here is a look at the top of the 50D.

- ♦ **Mode dial.** Turning this dial selects the shooting mode, which determines how much control you have over image exposures. Shooting modes are grouped into three zones including the Image, or automatic, Creative, and Camera User Settings zones. Automatic shooting modes are CA (Creative Auto), Full Auto, Portrait, Landscape, Close-up, Sports, Night Portrait, and Flash Off. Creative Zone shooting modes are P (Program AE), Tv (Shutter-priority AE), Av (Aperture-priority AE), M (Manual exposure), and A-DEP (Automatic depth-of-field AE) modes. The third zone, Camera User Settings, encompasses C1 and C2, shooting modes that you can program with your favorite settings. Just turn the dial to line up the shooting mode that you want to use with the white mark to the right of the dial.

Cross-Reference

Shooting modes are detailed in Chapter 3, including the noncustomizable shooting modes. Chapter 5 explains how to set up the customizable C1 and C2 modes.



1.4 EOS 50D top of the camera

♦ **Hot shoe.** The hot shoe mounting plate with flash sync contacts is where you mount an accessory flash unit. The 50D hot shoe is compatible with E-TTL II auto flash with accessory Canon EX-series Speedlites and supports wireless multi-flash support. When using a 580 EX II Speedlite, the 50D offers flash configuration from the camera using the Set-up 3 (yellow) menu. The camera also provides Flash Exposure Compensation to decrease or increase the flash output by up to plus/minus 2 stops in 1/3- or 1/2-stop increments.

♦ **Dioptic adjustment knob.** Turn this control forward or backward to adjust the sharpness for your vision by -3 to +1 diopters. If you wear eyeglasses or contact lenses for shooting, be sure to wear them as you turn the dioptic adjustment control. To make the adjustment, point the lens to a light-colored surface such as a piece of white paper or a white wall, and then turn the control until the AF points are perfectly sharp and crisp for your vision.

- ♦ **Focal plane mark.** The mark indicates the equivalent of the film plane and is useful in macro photography when you need to know the exact distance from the front of the image sensor plane to the subject.
- ♦ **LCD Panel Illumination button.** This button is tucked to the far left of the buttons above the LCD panel. Pushing the LCD Panel Illumination button turns on an amber light to illuminate the LCD panel for approximately 6 seconds. This is a handy option for making LCD panel adjustments in lowlight or in the dark.
- ♦ **Main dial.** The Main dial selects a variety of options. Turn the Main dial to change first named option on the dual-function buttons, cycle through camera Menu tabs, cycle through autofocus (AF) points when selecting an AF point manually, set the aperture in Av and C modes, set the shutter speed in Tv and Manual (M) modes, and shift the exposure in Program (P) mode.
- ♦ **Metering modes.** The choices include Evaluative (35-zone TTL full-aperture metering), Partial (9 percent at center frame), Spot (3.8 percent at center frame), and Center-weighted Average.
- ♦ **White Balance.** Choices include Auto (3000-7000 degrees Kelvin (K)), Daylight (5200 K), Shade (7000 K), Cloudy (6000 K), Tungsten (3200 K), White Fluorescent (4000 K), Flash (6000 K), Custom (2000-10000 K), and K (Kelvin Temperature, 2500-10000 K).
- ♦ **AF mode/Drive mode button.** Pressing this button enables you to change the Autofocus mode using the Main dial, or to change the Drive mode using the the Quick Control dial. The options for each are listed here:
 - **AF modes.** The choices are One-shot AF, AI Focus AF, and AI Servo AF.
 - **Drive modes.** The Drive modes you can choose from are Single-shot, High-speed Continuous (6.3 frames per second, or fps), Low-speed Continuous (3 fps), and Self-timer (10- and 2-sec. delays).
- ♦ **ISO/Flash Exposure Compensation button.** Pressing this button enables you to change the ISO sensitivity setting using the Main dial or the Flash Exposure Compensation using the Quick Control dial. The options for each are as follows:
- ♦ **Metering mode/White Balance button.** Press this button to change the Metering mode and/or the White Balance settings. To change the Metering mode, turn the Main dial, or to change the White Balance, turn the Quick Control dial. The options for each are as follows:

Note

Although the features are discussed with the dials, you can check out Table 1.1 for a quick reference for using the Main dial and Quick Control dial with the LCD Panel buttons.